

# Order Package - Doors

Use the following guide when making selections for your order.

## Step 1: Choose the wood species



Alder/Knotty Alder



Birch



Cherry



Hickory/Knotty Hickory



Knotty Pine



Paint Grade



Red Oak



Soft Maple



Walnut



White Maple

## Step 2: Choose the series shape



A - Square



B - Cathedral



C - Small Arch



D - Big Arch



E - French Cathedral



F - Slab



G - Mission

## Step 3: Choose the stile & rail profiles



1 - 261



2 - 265




3 - Shaker




4 - Shaker Bevel



4V - Shaker V-Groove



5 - 267



6 - 265 Recessed



7 - 266



8 - 268




9 - 269



10 - 264



11 - 262




12 - Shaker Slant




13 - 30 Degree Bevel

# Order Package - Doors

Step 4: Choose the insert profile



Step 5: Choose the outside profile



# Order Package - Drawer Fronts

